

DEVICE APPLICATION SCHEDULE		
INSTALLATION	MIN. STILE	BACKSET
TWO VERT. ROD DEVICES	3 11/16"	2 3/16" *
VERT. ROD & MORTISE DEVICE	SEE TEMP. W10305	2 3/4"
SINGLE DOOR	3 11/16"	2 3/16"

NOTES:

1. \*BACKSET MAY VARY WHEN USED WITH COORDINATOR DEPENDING ON TYPE USED. USE 2 3/4" BACKSET FOR WOOD FIRE DOORS.
2. REMOVE GLASS STOP OR BEAD IN AREA OF DEVICE IF REQUIRED UNLESS GBK IS USED.
3. MOUNTING HOLES TO BE PREPARED AT INSTALLATION ON DOOR.
4. FOR OUTSIDE TRIM PREPARATION, WHEN REQUIRED, SEE ADDITIONAL TRIM TEMPLATE.

LHR APPLICATION SHOWN,  
RHR APPLICATION OPPOSITE

5/8" DIA THRU TO  
CYLINDER CUTOUT

CL DEVICE

3/8" R

2"

1 3/4"

8"

39 5/8"  
TO FINISHED  
FLOOR

3/8"

3/8"

SLOT THRU TO  
TRIM CUTOUT  
OMIT FOR NL

⑥  
RECOMMENDED DOOR UNDERCUT IS 1/4" FROM  
FINISHED FLOOR (PANIC & FIRE) OR 1/8"  
FROM THRESHOLD (PANIC ONLY).

INSIDE FACE  
OF LOCK STILE  
LHR DOOR

9827/9927 & 9827-F/9927-F NL, TP, K, & L  
Series Vertical Rod Device (Wood Door)

**VON DUPRIN®**

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE  
NUMBER:

W10304\_a

DATE:  
05-29-13