

## K2100LL.SASHLOCK

Notes relating to door preparation.

Please review the catalogue extract to familiarize yourself with the finished appearance of the installation.

Establish the secure side of the door and thus the handing of the lock.

1. Please install the lock case using the template provided with the night latch lock case but taking note of the hand written amendment – i.e. **do not drill the hole marked**.
2. The lock case has a 60mm backset and this will dictate where the door is drilled to accept the fixings for the outside lock body (**passage snib only**). Use the template provided with the Keylex lock body but take note of the hand written amendment – i.e. **do not drill the holes marked (at the base of the lock body)**.
3. The Keylex lock body has been prepared with a modified back plate providing pillars to align with the holes adjacent to the follower on the sash lock case. This will allow fixing of the inside lever.
4. The spindle may need to be cut accordingly to suit the door thickness whilst ensuring it locates sufficiently into the lever to allow the grub screw to engage properly.
5. Feed the spindle through the door ensuring that you have set the spindle to suit the hand of the lock.
6. Fix the inside lever accordingly and clip the rose over the fixing plate.
7. Test the handing and code setting before allowing the door to close.
8. Install the cylinder/turn (by others if required) in the usual manner along with the escutcheon set if provided.
9. Code and passage turn operation is as laid out in the instruction sheet provided.
10. Any questions – call Mr John Livesey 01380 729600.